GSM-Support ul. Dobrego Pasterza 102/5, 31-416 Krak·w
mobile +48 608107455, NIP 8133358609 REGON: 181081334
www.gsm-support.net

Infinity Box

Infinity Box jest obecnie najlepszym narzňdziem do obsługi telefon·w marki Panasonic. JuŨ teraz za pomocŃ jednego przycisku moŨesz bez problemu odblokowaÍ czy teŨ naprawiÍ najnowsze modele tej marki! JuŨ teraz moŨesz odbudowaÍ uszkodzony numer seryjny, zmienic jňzyk, oprogramowanie, przywr·cic ustawienia fabryczne czy tez odblokowac telefon. Dzieki wykorzystaniu ğŃcza USB nie musisz uŨywaÍ dodatkowego zasilania, r·wnieŨ caąa transmisja odbywa siň po porcie Usb, co gwarantuje maksymalna prňdkoŜÍ tranmisji. Przy zakupie otrzymujesz kompatybilny zestaw kabli oraz unikalny dostňp do supportu producenta oraz przyszğych aktualizacji. Najnowsza aktualizacja umoŨliwia odblokowanie kaŨdej wersji Panasonica X70, NEC e101, N342i, Philips 568, Siemens CFX65, Motorola Acer, VK, Alcatel E15x/16x/25x, Benq, FLY, Newgen, Toshiba, Hyundai!

Kluczowe cechy (sprawdŦ dostňpne opcje dla kaŨdego modelu)

- szybkie odblokowanie SP
- szybkie flashowanie
- zapis kaŨdej czŃŜci flasha oddzielnie (gğ·wny, flex, mapa, FFS, paczki jňzykowe)
- naprawianie IMEI
- usuniňcie / wyczyszczenie blokady uŨytkownika (kod telefonu)
- ustawienie domyŜlnych ustawieŒ telefonu
- naprawianie "martwych" telefon·w
- duŨe baza danych plik·w z flashami dla kaŨdego regionu Świata; lista plik·w flash dostňpna jest w strefie darmowego supportu

Obsğugiwane modele telefon·w:
Ace: H1, other
Ace-Mobile: M12, other
Aiko: 17G, 51G, 52G, 70w, 78G, 97G
Airam: M342
Airness: Air99, MK99, Slide99
Airtel: Avvio-G200, Cordless_FGD8900, Telular
Ajanta: Quartz, other
AK-Mobile: AK760i, AK900
Alcatel: 103X, 203A, 280X, 303A, 303X, 363A, 363X, B331, C700A, C700X, C701A, C701X, C707X, C717A, C717X, C820A, C825A, C825X, E100x, E101, E15x_16x_25x, E201, E205, E207, E221, E227, E230x, Elle-N3A, Elle-N3X, F330X, F331, GlamPhone-EL05A, I650A, I650X, Lava, Mandarina-Duck-MD01X, Mandarina-Duck-MD02X, OT152, S100, S107, S120, S121, S210, S211, S218X, S319A, S319X, S320X, S321A, S321X, S520A, S520X, S521A, S521X, S621A, S621X, S626A, V212, V212C, V270, V570A, V570X, V607A, V670A, V670X, V770A, V770X
Alfatel: H1, H1A, H2, H3, H4, other
Altrec: C200, other
Amstrad: S288
Amycool: D66+, other
Anycall: 1689, 2619, D900, F488E, i718, i738, i908, i908e, S628, other
Anycool: 007, 629, 6300, 7310, D1200, D1210, D3000, D38, D528, D6000, D66, D66+, D68, F1000, F58, F69, F818, F888+, F999, GC668, GC778, i908e, i929, i939, Kingbond-KDI-D528, N101, N86, T618, T618+, T619, T628, T648, T718, T728, T808, T808-TV-Phone, T818, T828, T838, TV188, V168, V520, V7000, V777, V866, V868, V9, V9+, other
Anylink: 6500, N99i, other

Anyoall: 908i, SGH-908i, other
Aobang: A880, other
AOTE: 660, 908, 918, 928, F9+, M660, other
Apole: IP9300, other
Appo: A300, other
ARA: A818, other
Arte: 8600e, other
Asiafone: AF501, AF502
Asus: J202, J206, J208, V66, V75, V80, other
Atan: M760, M760-Music-Phone, other
AT-Telecom: Hi-Messenger
Audiovox: GPRS748, GSM609
Austar: F455+, other
AUX-Mobile: M780, M855, M868, Z33, other
Avivo: 1950g, 1960g
Avvio: 103A, 203A, G200, GD851p, GD852p
Awang: A828, A929, other
A-ZED: Z62, other
Bacha: ZMC888, other
Baizhao: S320i, S600, S8958, TV488, other
Bak: BK-MP77, BK-MT77, MP605, other
Bao-Xing: N200, other
Basicom: M-Star, V9, other
Bavapen: 104e
BBK: i399, K300, K322, S202, other
Beetel: EC003, EC005
Bellwave: N77, other
BenQ-Siemens: A38, A500, A53, C30, C71A, CF51, CF61, CL71, E52, E61, EF51, EF61, EF71, M100, M220, M300, M305, M315, M350, M580, S660C, S700, S80, S81, S82, S88, SFG75, T33, T51, T66, Z2, other
Bess: SP500, SP770
Best: D2000, D2000+, D3000+, D3800+, other
Bestel: 6000+, D5000, D5000+, N95, other
Bestking: A2688, other
Bestone: KA08+, other
Beyond: B333, B510, B515, B530-SL71, B555, B600, B818, B868, other
Bird: D515A, D611, D612, D615, D630, D650, D660, D670, D706, D716, D720, D730, D736, D760, F300, F501A, F518, S1120, S1180C, S1186, S198, S199, S288, S299, S302, S305, S570, S688, S699, S701, S710, S788, V09, V10, V5518+, V620, V708, V750, V788, V789, other
BK: MP605, MP725, MP728, other
Blacklable: VVV363, other
BLCOM: V8, other
Bleu: 151x, 245x, 251s, 251x, 255x, 351x, 354x, 355x, 450z, 453x, 454x, 456x, 466x, 471x, 476x, 550x, 551x, 555x, 651x, 651Z, 670x, 670z, other
Bliss: D108, D208, V98, other
Bluetooth: 2008, 2009, 2600, 2640, 337, 339, 349, 526, 536, 588, 588+, 589, 626, 6500s, 6688, 6888, 6889, 808, 868, 888, 8928, 900, 900+, 911, 912, 998, 999, A20P, A5, A5688, B889, C800, C8000, C8800, C905, C92, C98, D18, E588, E70, E78, G366, G368, i738, JD2008, K320, K328, K400, K440, K799, KN-D9, L831, L832, LV918, N77, N77S, N78, N79, N79C, N82, N83, N8600, N91, N95, N958, N97, N98, N98+, N99i-TV, PDA, S30, Slim, TC-168, V168, V21, V55, V555, V648, W726, Y138, Y139, Y690, ZT588, other
BMW: A8, other
Bolo: C62, C68
Bonmi: F430, other
Bossh: B70, D96M, other
Bost-Mobile: D615
BPL-Mobile: COLT027, other
BSNL: EC005, G200CF
Bugatti: 164, other
Buss: G618, other
BX: N5000, other
Camry: V138, other
Capitel: P600, other
Cect: 003, 1088, 1280SM, 199, 2000, 3360, 505, 5708, 599, 6300i, 6300R, 6600, 668, 688C, 688i, 689C, 689i, 760, 761, 7708, 808, 8100, 8110+, 838+, 8380, 8380-PDA, 8380-TV-OUT, 858, 860, 8800, 8808, 888, 888+, 9898, 9988, A008, A100-TV, A1600, A1800, A1818, A2000, A520, A606, A666, A6668, B8, C1000, C1000i, C2000, C2000D, C3000, C3000c, C5000, C5188, C600, C6111, C8000, C8200, C8220, C827, C828, C829, C8400, C8600, C92+, C9900, D120, D122, D240, D242, D900, E591, E65, E65C, E65i, E680, E680i, E808, E818, E900, E920, E921, Edalee, F1200, F16, F22, G928, GP9000, H6628, I530, i658, i70, K2, K300, K300+, K328, K630, K770, K7800, K808, K818, K828, K838, K838+, K86, K915+, KG98, L2000+, L2200+, LM398, LT-X3, LV918, M1818, M1818-PDA, M520, M530, M619, M800, M8600, M901, N1000, N168, N1818, N518, N528, N529, N537, N538, N548, N618, N618+, N618c, N6298, N6500, N6500+, N73, N73-1, N73i, N788, N81, N81+, N81c, N82, N84, N85, N87, N95, N95-PDA, N98, N99+, O2R, P168, P30, P3711, P3711i, P3714, P3715, P603, P8100, P8100+, P8300, P8400, P9100, Q300, Q300A, Q300C, Q302, Q306, Q380, Q500, Q500-2sim, Q500BT, Q558, Q600, Q610, Q618, Q618-2sim-PDA, Q638, Q800, Q86, S500, S500-O2S, S500-PDA, S500-PDA-02Mini-3D-S, S500-PDA-02Mini-3D-

Sound, S510, S560, S560-MPEG5, S567, S580, S588, S800, S800+, ST500, T1, T100, T410, T520, T590, T6688+, T678, T688i, T688i-2sim, T688-PDA, T689, T718, T830, T888, T910, T918-WatchPhone, T999, T999+, TV60, U880, U8800, U8810, U90, U92, V180, V200, V23, V23i, V3, V329, V4, V400, V480, V490, V5, V6, V60, V60+, V61, V658D, V668, V6688, V668B, V68, V69, V7, V70, V777, V788, V8, V8008, V9, V90, V909, V919, V92, V929, V939, V98, X768, X768-GSM-CDMA, Y200, Y690, Y767, Y809, ZP-S560, ZT-V8, other
Century: Piooner-B889+, other
Cert: V400, other
Cesim: A510, CG400, N88, V130, V30, V310, V470, V480, V800, other
Changhong: A330, M838, other
ChangJiang: A968, other
Changxing: A868, other
ChinaStar: C507, S350, other
Chinese-Blackberry: 8900, other
Chinese-HTC: Diam100, P3700, other
Chinese-iPhone: 168, 188, 189, A1203, A38, A380, A39, A58, A6, A6+, A7+, A8+, A88, A88+, A888, A9, C8000, ES350, ES358, i9, KA08, LH01, N500, N5000, N5005, N5100, N5200, N5500, P168, P168+, TV-3G, TV-4G, V188, W888i, other
Chinese-iPod: A380, other
Chinese-Motorola: 400, 608, A1200, A606, K1, L7+, V230, V3, V33, V333, V336, V666, other
Chinese-Nec: 1000i, N150, N158, N880, N880i, N99, other
Chinese-Nokia: 1110i, 1111, 1112, 1112i, 1600, 3230, 3230C, 3250, 3280, 3680, 5200, 5300, 5300i, 5310, 5310-NMM-3, 5310XM, 5320XM, 5330, 5331, 5332, 5610, 5610D, 5610D-1, 5700, 5700+, 5710, 5720, 6110, 6118, 6120, 6120+, 6120C, 6120i, 6128, 6131i, 6200, 6233i, 6275, 6276, 6280, 6280i, 6288, 6288-PDA, 6300, 6300C, 6300i, 6300-Q7, 6300-Q7+, 6300r, 6300-RM-217, 6300y, 6500, 6500+, 6500c, 6500s, 6600s, 6621, 6680, 6681, 6700i, 6708, 6808, 7210c, 7210v, 7260, 7310c, 7310e, 7380, 7390, 7500, 8003, 8030, 8030-2sim, 808, 8600, 8600d, 8800, 8800+, 8800A, 8800-Arte, 8800e, 8800e-1, 8800e-Arte, 8800i, 8800S, 8800-Sirocco, 8830, 9900, A200, A6+, A606, Arte-8800, BB7, BB7+, C60i, C85, C88, C88i, C92, C93, E50, E51, E55, E60, E60i, E60-PDA, E65, E65i, E66, E66+, E66i, E66y, E68, E71, E71+, E71i, E75, E77, E78, E78c, E86, E89, E8-Touchpanel, E95, F69, GC690, HT508, K288, K288-MPEG4, K915+, M5700+, M77, M78, M79, M9, M90+, M96, M97, MM95, N1000, N12, N125, N126, N129, N135, N151, N153, N157, N177, N203, N203i, N204, N204i, N207, N207i, N22, N26, N28, N288, N28i, N290, N303, N321, N366, N366i, N368, N39, N4, N41, N5, N50, N500, N5177-2sim, N52, N52i, N54, N55, N56, N57, N57i, N57i-2sim, N600, N606, N608, N616, N618, N618+, N65, N6500, N658, N66, N66-2sim, N666i, N668, N66C, N66i, N66L, N67, N67i, N68, N688, N688i, N689, N7, N70, N70C, N70DK, N70i, N70-TVphone, N71i, N72, N72i, N72L, N73, N730, N73-2sim, N73C, N73C-2sim, N73D, N73F, N73G, N73i, N73L, N73-music-edition, N73-PDA, N74c, N75, N750, N750+, N751, N75c, N75i, N76, N76c, N76i, N76m, N77, N771, N772, N777, N777i, N77i, N78, N78-2sim, N788, N78s, N79, N7i, N80, N800, N8003, N81, N81i, N82, N82_20pin, N8201, N820i, N82i, N83, N83c, N83i, N84, N84i, N85, N85i, N86, N8600, N8600-Luna, N86i, N87, N87c, N87i, N88, N8800, N8800L, N888, N8888, N88A, N88c, N88i, N88s, N89, N9, N90, N900, N900i-2sim, N903, N903i, N905, N905i, N90i, N90s, N91, N915+, N91A, N91i, N91i-TV, N92, N920i-2sim, N922i-2sim, N927i-2sim, N92G, N92i, N9-2sim, N93i, N93i-2sim, N93i-TV, N94, N94i, N94s, N95, N95+, N95-2sim, N95-8G, N95-B10, N95C, N95e, N95i, N95i-2sim-music-edit, N95i-2sim-music-edition, N95i-slider, N95i-TV, N95-PDA, N95s, N95S-2sim, N95-slider, N95-TV, N96, N96i, N96i-2sim, N96-PDA, N972, N973, N97i, N97k, N98, N98G, N98i, N98i-TV, N98i-Visoa, N98K, N99, N990, N99-2sim, N99B, N99i, N99N, N9s, O3-838, P1I, Q2R, Q7, Q7+, RH-73, S728, S89, T158, T57, T58, T98, TP012, TV1000+, TV1100, TV2200, TV5, TV5188, TV690, TV7, TV702, TV8800, TV90, TV98, V23, V230, V25, V27, V400, V8800, V909, V95, V96, V98, Veptu, Vertu, VT1300, VT9, other
Chinese-Other: 2928, 2GSM, 3188, 338, 3D-Sound-V23, 3GSM, 6500s, 736, 808, 818, 828, 829, 838+, 9900, A108, A1168, A1308, A16, A17+, A1966, A2000, A203, A20P, A2198, A308, A328, A380, A520, A550, A628, A638, A6398, A6399, A666, A68, A7+, A700, A706, A8+, A818, A898, A900, A930+, A950, A960, A968, A968+, A969, Adidas, B889, BT888, BX-E71i, C600, C702+, C902, C902+, C904+, D820, D900, DVD, E66, F488, F492, F698, F838, Ferrari, FY5900, G618, Gionee, GM259, H668, H688, H689, HB758S, i1000, i1100, iPhone, JC51, JC678S, JC699S, JC730+, JC730S, JC777, K188, K300, K3000TV, K328, K3288, K588, K589, K666, K808, K8800TV+, K888, K915, K916, Kangaroo, KittyPhone, L7, L700, L707, L8000, L8080, L999, LC-C4, LT-X1, LT-X5, Luna, LV918, M2210, M606, M777, M868, M869, M8800, M905, M910, MD-477TSIP, MK168, Mobile-2007, MStar, N100, N107, N203, N203-K1, N28+, N328-GSM+CDMA, N600, N6555, N69, N760, N77, N880, N88D, N980i, Navigator, P990, P990i, PDA-328, PDA-6688, PDA-W726, Perfect-2g, PowerPack-TC-2GSM, Q7+, Q77, Rolex, S1288, S2199, S350, S351, S357, S68, S728, S73, S760+, S760TV, S780+, S808, S813, S817, S90, S97+, S98+, SE318, SE818, S-Mobile, Sonic, SuperFone, T158, T2600-683, T320, T63, T67, T678, T69, T698, T69i, T737, T788A, T800+, T807, T88, T89, TagHeuer, TagHever, TT-V1, TV1100i, TV12, TV200, TV2009i, TV55, TV600+, TV-6208, TV628, TV683, TV687, TV690, TV886, TV88SQ, TV9, TV90, TV902, TV988+, TV998, TV-C1000, TVN95, TZ-Y500, V100, V168, V188, V333, V50, V5000, V52+, V57, V628, V660, V668, V68, V800, V807, V808, V9, V918, VS400, W726, W726-PDA, W726-PDA-2sim, WatchPhone, X909, X-SLIM, Y500, Y600, Y690, YZ09, Z100, ZH6688, ZS89, ZT320, ZT321, ZT5099, ZT689+, other
Chinese-PDA: 520, 520+, 628, 628i, 6680, 6681, 8810i, 8850i, A1196, B889, D328, E590, E591, E592, L5688, Mobile-T88, MP4, MPEG4, T88, TV-Mobile-A9000, V13, X2, X3, other
Chinese-Pocket-PC: 1688-2sim, 6600, N77, N78, N87, N95, N95i, N99, other
Chinese-Samsung: 629+, A838, Armani, D500i, D520i, D600i, D800, D820, D828, D828+, D829, D860i, D900, D900+, D900i, D920, D958, E680, E700, E708, E708+, E712D, E730, E730+, E730C, E738, E760i, E900, F300, F488c, F488e, i788, i888, i900, M8800, P528, P538, Q101, S9402, SGH-629, U800, U900, U908e, X180, X810, X810+, other
Chinese-Sharp: GX18, GX28, P810, other
Chinese-SharpV: P810, other
Chinese-Sony-Ericsson: A580, K288, K750, K750C, K750i, K758, K790i, K800, K800i, K808, K809, K810, K810i, M61, P800, P990i, T650i, V666, V700, W580, W610i, W660, W700, W800, W800i, W880i, Z610i, other
Chinese-Spreadtrum: SC6600M
Chinese-Toshiba: E315, V10++, V11, other
Chinese-Vertu: 998, Ascent, Ascent-Ferrari, Ascent-I, Ascent-Indeanapolis, Ascent-Ti-RM-267v, Constellation, Ferrari, Ferrari-F1+, Ferrari-II, Ferrari-III, Ferrari-RHV3, LY-8088, MC2, Narnia-V6-Mini, Royal, Royal-R1, Signature, Signature-

RH267, Signature-RHV8, Titanium, V1, other
Chiva: LM718, ST319, UK598, other
CKing: 339, K339, other
Coby: MP777, other
Cool: ATL-V8, other
Coral: 100, 200, 200FM, 300, 400, 400FM, 500, 500FM, 620
Cosun: 289, 512, 8266, 8988, C512, N73i, other
Cross: G10, GG53, GG55, other
Cvfd: M31, other
Cyber-Shot: E860, other
Cyfon: C800i, other
Cynix: D28, D38, E49, other
CZCT: C8000, other
Daewoo: D600, other
Daxian: 619, 669, 8100, C8100, E689, J168, J6, N800, P168, T108, X3000, X658, X728, X756, X780, X799, X9188, X960, X960-FM, X999, other
DBTel: J6
Desay: K618, L608, M523, M535, M888, N618+, N618i, other
Dfashion: Z3, other
Diamond: T8800, other
Digibee: BSNL-G200CF, G240
Digiphone: E711, other
Digital: C500, other
Dirland: E307, M881, P708, R100, X410, other
D-One: DG518, DG-518, other
Donod: D805, D806, other
Dopodo: C95, C97, C99, C99+, E57+, E61+, E62+, E63+, other
Dorado: A006, D111, D380, D890, other
Doro: HandleEasy-328gsm
DRV-Mobiles: R52, other
Dsney: M6, N8, Q7, other
Dubao: 538, 558, 728, 728+, 738, 758, 768, 768+, 777, other
DVD: S618, other
DV-Phone: V93i, V96i, V97i, other
Easycall: 6600, other
Einstein: MC2, MC3, Singular, other
Ektel: C1-TV, other
Elenberg: MT105, MT320, MT520, other
Elgin: EL-MP730, other
Elitek: GT101YN, other
Eliya: S168, other
Elson: E800, ESL808, MP500, SL308, SL900
Emblaze: Sting6, Touch7
Enimac: MQ8200, other
Enteos: i-BD620
Epoda: EP2502, other
Etel: E12, other
E-Tel: P9, other
E-Top: S30, other
E-Touch: 1133i
Everfo: 2601, 2602, 2603, 2604, E2211+, E32, E591, E711D, E713D, E730, E863, E866, E911, E912, E927, E941, other
Evertek: X9, X90, other
Experta: X1, other
Ezio: E300, E800, ESL808, MP500, SL308, SL900, other
Fashion: A5688, T508, T588, other
Ferrari: F1, HC668, LV2008, other
FixMobile: A969, other
Fly: 2040, 2040i, 2040L, 2060, 2080, B600, B700, DS400, DS500, E100, E105, E300, E310, FT10, Hi-SLDR, Hummer-HT1, Levis-LV1, LX500, LX600, LX610, LX800, M100, M130, M140, MC100, MC120, MP100, MP220, MP300, MP400, MP500, MP600, MX200, MX200i, MX230, MX300, MX330, SL100, SL200, SL300m, SL399E, SL400m, SL500i, SL500m, SL600, SL600-Vodafone, SLT100, SX100, SX200, SX210, SX215, SX220, SX225, SX240, SX300, SX305, SX310, SX315, V100, V40, V50, V60, X3, X7, X7a, Z200, Z300, Z300a, Z400, Z500, other
Flying: F636, F639, F67, F69, F698i, F800, F826, F900, F916, F936, F996, other
Fly-Ying: F003, F036, F99, other
Fory: F288, other
Foston: 968B, FS-829, FS-836B, FS862, FS-868B, FS968A, FS-968A, PDA, other
Fujistar: FT-1011, other
FUN: N100, N73, N77, N78, N95, other
FunnyMobile: V20, other
Galaxy: T81, other
Game: 5300, other
Gaoxinqi: A818, D601, E908, E908i, GXQ-F896, GXQ-N358, N82, N87, T838, TL528, other

GeneralMobile: DST01, DST10, DST11, G333, other
GEO: G1, GV500, Gv880
Getek: TK806, TK808, other
GFive: T33+, other
Gibox: MK369, MK397, other
Gionee: A10-TV, A830, L7, L8, V5600, V890, other
Giorgio: Arnan-F8, other
Giorgio-Arnani: dual-sim, other
GlobalMobile: G0003, other
Global-Mobile: G0003, other
GLP: 138, 138GT, other
GMobile: T68, other
G-Mobile: N82, other
G-net: G409-mini, other
Goldvish: Signature-RHV-2, Signature-TRGH-8, other
GPS-Mobile: K3288, other
Gradiente: GC300, GF500, GF760, GF910, GF910i, GF930, GF930i, GF950, GF970, Vibe
Gross: G10, other
GSmax: GS868, other
G-Star: 618, 808, G2, G6, G851, GM108, GM128, GM208, GM209, GM238, GM308, GM318, GM328, GM329, GM338, GM508, GM528, GM608, GM618, GM618-Slim, GM809, GM851, GM896, GM896M, other
GT: V100, other
G-Tide: L600, W110, W310, W510, W520, W620, W660, other
GT-Mobile: 1268, 1400, 450, i1268, M300, M920, TV100, TV70, TV-70, other
Gtran: N120, N150, N510
Gucci: G600, G629, G668, other
Hagenuk: Jazz
Haier: G111, HG-A8, HG-M307, HG-V70, M300, M500, S210, Z1000, Z1600i, Z702, other
Hantel: 6088, D1838, E860, H168, H625, HN9398, HT3188, HT6600, HT8388, M2210, Send-Y500, other
Hedy: H797, other
Hidden-Dragon: N68, other
HiPhone: V188, other
Hisong: M920, other
Hitech: H31, H38, H382, H39, H55, H61, M21, other
Hitune: A4, other
Holleycomm: H3101, H3260, H3270, other
HTC: A288, TouchFLO-P3452, other
Huawei: C2205, C2285, C506, T128, T156, T158, T160L, T161L, T201, T202, T206, T208, T211, T261L, T330, T711
Huaxiang: N800, N900, other
Huaxi-Ang: N800, other
Huayu: CM336, CM591, CM618, CM678, FT688, G688, K878, K888, L787, L888, M818, P30, V928, other
HUG: Q88i, other
Hutch: Usha-Lexus-UL2104
Hyundai: H350, L480, MB-115, MB-121, MP318, MP510, MP718, MP728, MP738, MP880, W100, other
HZTel: S400, other
Ianus: 999, other
iCool: A520, other
iFOE: P168+, P168C, other
IMax: C82, other
Imo: 168, other
I-Mobile: 100, 101, 200, 301, 306, 308, 313, 315, 318, 508, 510, 511, 516, 518, 520, 523, 600, 601, 602, 603, 604, 606, 608, 609, 609i, 610, 611, 901, 902, 903, BlackIce, CE0680, CE0889, CX-K809, other
iMODO: IM100, other
Infinity: 2in1, 5800-2sim, Q500, S380, other
Innostream: Inno-900, other
Innovo: i8510, other
Intex: IN0315, IN1044, IN1107, IN1224, IN2010, IN2020, IN2020FM, IN2030, IN2222, IN2233, IN2244, IN2266, IN3060, IN3333, IN40, IN4040, IN4444, IN4466, IN5050, IN5544, other
iPhone: N5000, other
Irion: 9108DS, other
ITel: C8000, IT207, IT600, IT700, IT800, other
i-TV: V10, other
Jaga: TT678, other
Jazz: T161L
JFS: N5000, other
JiaXing: N95, N97, N98, other
Jincen: JC51, JC618S, W400s, other
JingCheng: JC666S, other
Jinke: E100, E100-TriBand, other
JinPeng: 488, 5199, 768, 8188, 8190, 8198, 8283, A09TV, A5616, A5658, A5688, A606, A616, A666, A7522, A9, A928, B798, C3000, E1088, E2298, E55, E6180, E88, JP1688, K330, K939, K989, K999, M8, M868, S2128, S628, S688, S7310, U900, V70, V70FM, other

J-Max: F10, J95, J-Diamond, JM5700, Saxy, other
JNC: MX8, other
J-Tide: C28, G880
Jugate: Z-AD928, ZJS638, other
Kaiqi: N107, TV32, other
Karamfone: S4, X5, other
Karbonn-Mobile: K118, K330, K450, other
Kedaq: Q191, other
Kejian: K508, M680, other
Kenuo: KD-B86, KN-76D, KN-A75D, KN-D8, KN-D9, KU-D9, N750, other
Kiech: N8899, other
Kifung: S108, other
King-One: K608, other
Kingpo: E302, E320, E733, other
Kinlong: K228i, K288+, N96, other
Kisen: 3000, F350, K1, K2000, P83, V633, other
KIT: LC-888, other
Kitty: 318, 328, 348, other
KLoong: A913, E714, E718, other
KN-Mobile: KN200, KN300, KN310, KN400, KN500
Konka: A26M, A76, A76FM, C623, C625, C635, C636, C676, C926, C966, D163, D169, D225, D266, D363, D620, EC001, EC001FM, EC003, M520, M910, other
Kotka: E90, E97, E98, other
KTech: 8020, 8030, 8030i, 8388, K400, N8899, other
KTouch: A5118, A615, A650, A905, A933, B718, B830, B922, B923, B938, C800, D700, D702, S515, V918, other
K-Touch: A615, V908, other
KXD: 001, 012, other
Kyocera: C2500, E2500, E3500, E4600, S1600
Laise: N99, other
LDF: K9000, other
Leady: C506, GT6107, MM10, MM95, X105, X501, other
Lenovo: 688, E300, E307, E520, i706, i908, i909, P618, P708, P710, S5, V707, V800, other
LG: 300G, B2000, B2050, B2060, B2070, B2100, B2150, B2250, C1100, C1150, C1200, C2200, C2500, C2600, C3300, C3310, C3320, C3400, F2250, F2400, G1800, GB102, GB125a, KE260, KE600, KE770, KE800, KE820, KE850, KE970, KF600, KG110, KG120, KG130, KG180, KG190, KG195, KG200, KG208, KG210, KG220, KG225, KG240, KG245, KG270, KG271, KG275, KG276, KG278, KG280, KG285, KG288, KG289, KG290, KG291i, KG295, KG296, KG300, KG320, KG370, KG375, KG70, KG90N, KM330, KM335, KP100, KP105, KP106, KP110, KP115, KP130, KP135, KP199, KP200, KP202, KP202i, KP210a, KP215, KP215A, KP220, KP230, KP235, KP320, L342i, L343i, ME770, ME850, ME970, MG100, MG101, MG105, MG110, MG120, MG125, MG160, MG161, MG165, MG170, MG180, MG225, MG230, MG235, MG280, MG296, MG320, MG370
Libercell: KT400, KT500, KT8800
Life: DST01
Lion: 12, 7, 8, other
Lipiec: T800, other
Lobster: 485, 544, 575, S621
LongTel: S88, other
LongXing: M3, other
Lontin: E71i, RH165-E71i, other
Louis: V168, other
Louis-Yuitton: T658, other
LUNA: 8600, 8600d, N688, other
Luxury: G851, other
LX-Mobile: 007, TV, other
Magicon-Harmony: MG901, other
Malata: Lopp-P07, M696, MZ280, T256, other
Maximus: EX60, EX75, MX100, S70, other
MBM: 1168i, S95, S96, other
MD: 399TSIP, 455TSIP, 460TSIP, 462CPU, 465TSIP, 475TSIP, other
Medion: 2860, MD-95100
Meidea: Y1000, Y300, other
Meiye: N82, Q7, Q8, other
Melbon: MB-606M, other
Metom: M20TV, MT309, N11, N81, N82-TV, N87, N89, other
Mex: MX14BS, N95, N97, other
MFU: V200, other
Micromax: 511x, X113, X115, X1i, X1u, X211, X225, X414, other
Micxon: CTV-810, MTV800, other
Mikki: C90, other
Ming-Xing: A008, other
Mini: G89, other
Mito: 1868, 266GG, 288GG, other
Mobiley: NR1
Mobility: NG1

Modelabs: Airness-Slide99, Elite, MyWay-Slim, V-Slide, V-Touch
Moille: ZTC-ZT588, other
Motocom: C500, other
Motorola: C113(a), C114, C115, C115i, C116, C117, C118, C119, C121, C122, C123, C136, C137, C138, C139, C140, C141c, C155, C156, C157, C168, C168i, C257, C261, E365, F3, F3-unlock, V170, V171, V172, V173, V175, V176, V177, V690, V872, V878, W150, W150i, W170, W170C, W200, W205, W208, W209, W210, W212, W215, W218, W220, W355, W370, W375, W376, W377
Moviephone: FA6, other
Mox: MO778, MO800, MO875, MO875+, other
Mox-Mo: 698, other
MP4: 2000, 6188, O2-mini, O2R, O2S, O2S-Dopod, PDA-K18, other
MPEG4: 2000, 3000, 3200, 3210, 3300, 3320, 4000, 4100, A968, K1, P888, T698, other
MTK: MT228, other
MTV: N73, N97, N99, other
Much: D800, DS-850, other
Muzak: N88, other
My_Way: Modelabs-Slim, MW100, MW200, Touch
MyPhone: 3350, 8830TV, B21, B22, B23, B23-Duo, B25, B50, B50c, B71, Q21, S21, S22-Duo, T11, T12-Duo, T13-Duo, T22, T22-Duo, T52, other
MZ1: 1099
MZ2: 1099
Narnia: 8088, V6, other
NCBC: DFH688, other
Nckia: 3100, 5600i, 5610i, 5700+, 7390, E95, M5700, M5700+, N77, N77i, N78, N78c, N95, N95-8Gb, N97, N98, N99, XpressMusic-5610S, other
Nec: E101, E121, E122, N200, N208, N342i, N343i, N344i, N650i, N910, N916, N917, N919
NECcom: A007, A0078, A6, N880, N990, N990+, other
Nektel: C7000, other
Neoi: 809, other
Nerys: N330
NewGen: C1000, C610, C620, C650, C710, C800, E1000, E1100, E1200, Mars, S410, T1000
Newtone: NTi8, Q6, other
Nex: Mini, other
Nexcel: E71, other
Nexian: G500, NX-G700, NX-G900, other
Next: 809, 809-TV, other
NGM: DG689, other
Nkiac: F168, other
Nktel: 1680, 2008, 2800, 2850, 2900, 2970, 5310, A200, A210, A220, A300, A500, A60, A600, A700, A800, C2008, C3000, C5000, C6000, C7000, C8000, C9000, E280, K100, K99, N8600, S350, S358, other
Nobel: V8000, other
Noca: T856, T856-W88-PDA, other
Nokia: 1255
Nokier: F768, other
Nokig: N82, N97, other
Nokla: 1112, D328, E90, E92, N71, N72, N72c, N73-PDA, N77, N78, N79, N95, N95-2sim, N958, N959, N96, N96c, N96i, N97, N98, V98, other
Nova: N800, other
Nove: N800, other
Novo: C501, N717i, other
NTC: MyPhone-S21, MyPhone-S21 MModule", MyPhone-T11, other
O2: Jet(J1), O2X1B, O2X1I, O2X2i, O2X3, O2X4, O2X7, O2XLI
O3: 818, 828, 829, 838, other
Oaintel: E88, V88, other
Obee: 007, 007i, 680, K399, N78, other
Ocean: F3000, other
Odin: P1000, other
Omnipotence: Micky, other
Onida: F830, F910, G460, G520, V110, other
oooooo: C99, E99, N99, other
Oppo: A109, other
Orange: Rome, Tokyo, TR1, V101, Vegas
Orion: 910DS, other
Overtech: OT-09, other
Panasonic: A100, A101, A102, A200, A210, A500, G50, G51E, G51M, G60, G70, GD55, GD67, GD68, MX6, MX7, SA6, SA7, SC3, VS2, VS3, VS6, VS7, X100, X200, X300, X400, X500, X60, X66, X68, X70, X700, X701, X77
Panasonio: N75, V2000, V4000, V6000, other
Panda: 2008, 66, 67, Olympic, Olympic-Summer, other
Pantech: C120, C3, C3B, G3900, G800, G900, GB300, PG-1000, PG-1200, PG-1210, PG-1400, PG-1405, PG-1410, PG-1500, PG-3000, PG-3200, PG-3210, PG-3500, PG-3600, PG-3810, PG-6100, PG-C300, PN210
Papaphone: PP7, other
Pawan: 2975, other

Philips: 192, 199, 290, 292, 298, 390, 568, 768, 960, CT7688, E100, M200, S200, S220, S660, S800, S880, S890, X170, X800, Xenium-9@9u, Xenium-9@9w, other
Phoenix: P2000, other
PierreCardin: GM118, other
Piglet: L4, other
Planet: E3, M1, V2, other
Platinium: E71i, other
PlayboyPhone: PB01X
Players: P718, other
Porsche: Cayenne, other
Powerpack: TC-107, TC-1GSM, TC-2GSM, TC-BT3, TC-BT7, TCG-8801, TCGS-218, TCGS-8806, TCGS-8818, TCGS-8888, TC-TV-168, TC-TV-178, TCTV-278, TCTV-438, other
Prince: T760, other
Privileg: X6, X7, other
Qbest: Q380-B, other
Qiao-Shong: QS880, other
Rage: RU-2000-TV, other
Rainbow-mts: S189
RedStar: 901, 902-TV, 910, other
Reliance: Classic-7310, Classic-7610
Rex: P990, other
Rocky: 2008, other
Rolex: HK010, other
Safeer: 8800, other
Sagem: my150x, my220v, my220x, my225x, my226
Sambao: N78, N78i, N87, N95, N97, other
Samd: 900, 908, 918, other
Samkung: TV168, other
Sampo: GK8800, other
Samsking: V11, V12, V21, V21i, other
Samsong: E318, other
Samsunc: U800, U900, W579, other
Samsung: B300, C140, C140i, C260, C260M, C266, C300, E900, SCH-B189, SCH-B239, SCH-B259, SCH-B279, SCH-B309, SCH-B399, SCH-E159, SCH-F302, SCH-F679, SCH-S189, SCH-S229, SCH-S259, SCH-S269, SCH-S279, SCH-S299, SCH-S339, X120, X140
Sands: A203, A203i, A209, A303, A303i, A8, P908, other
Sang-Teng: Q7, Q7+, other
Sanke: S1, other
Sanno: 268, 6618, A88, N82y, N96i, N97, N97i, N98, N98k, T008, T628+, other
Sansui: V847, V909, V919, V929, other
Sanxing: E415, E70, E78, V52, other
Sany-Ericsson: W810i, other
Sanyo: S750
Schauen: N16, other
SCiPhone: G2, i68, i68+, i69+, S18, other
Scool: TZ209HIFI, other
SED: 838+, 950, AK606, AK606i, B908, B908-PDA, D968, DJ120, N08, N6128, S1000, SA833, V628, V630, V638, V639, V889, V890, X520, X688, X688-2sim, X689, X689+, X698, X716, X827, X941, Y690, other
Sentel: 81, other
SerteC: X3, other
Seven: DR1, DS2, DS3, DS4, other
SFR: 111, 195, 227, 228, 231, 232, 341, 342
ShengBao: A1000, other
Shen-Matel: V7+, other
Siba: 2632, other
Siemens: AP75, CFX65, CL75, SFG75, ST55, ST60
Sigmatel: 3600, 6100, 6110, 988+, E588, FXD, FXD-S22, FXD-S30, FXD-S77, FXD-T99i, S1, S18, S2, S3, S3+, S30i, S33, S4, S5, S76, S7700, S7700-GPRS, S7700-non-GPRS, S81, S88, S90, S91, S92, T300, T33, T33i, T55, T66, T96, T99, T99i, V88, W333, W999, other
Simbao: A800, A888, A890, A898, other
Simoco: SM1000, SM1100, SM322, SM366, SM377, SM399, SM466, SM488, SM498, SM499, SM611, SM633, SM988, SM999, other
Simtel: MStar, other
Simtelep: G-Star, Mstar, other
Sitronics: SM8190, SM8290
Sky: SK1
SkyMIX: 100, 300, other
Skyway: GC800, other
Skyworth: T508, other
Skyzen: EZ100, EZ200, EZ300, EZ400, EZ500, EZ600, EZ700, EZ800, N101, S3, S6, S8
Slym: N718, N728, TV, other
Smarj: S70, other

Smart: G831, G850, V555, V555-TwinCamera, V570, V800, V810, V840, other
Smartphone: TQ-K902, other
Sonaki: S888, other
Song: A168, W668, other
SongLive: C2000, other
Sonica: N8, other
Sony-Ericsson: J100(i), J110i, J120i, J121i, J132, K200a, K200i, K205i, K220i, K330, R300, R306, T250i, T280i, T303, Z250a, Z250i, Z320i
Soon-Ersson: K520i, K530i, K610i, K620i, other
Sotel: C500, N82y+, N95y+, other
SouthEast: 818, other
Spice: D80, D88, D88N, D90, M4580, M5252, S300, S400, S404, S404N, S410, S415, S450, S5, S500, S525, S530, S535, S540, S545, S555, S570, S580, S590, S600, S600N, S640, S650, S7, S700, S705, S707, S707n, S710, S8, S800, S808, S820, S9, S900, S920, S940, X1, other
Sprint: 7700, 7710, P50, S60, other
Spyker: C8-Laviolette
Startech: ST21i, ST22, ST67, ST88, other
StarWorks: M448, other
ST-Mobile: 0, S80, other
Strike: T915PC, other
Suaahoo: S709, other
Sucee-Tong: 908, 918, 928, 928i, 998, other
Suiya: SY-88, other
Sumsang: 840, QS840, other
Sun: N86, N87, N87i, N98, N99, other
Sunforce: K600, K600i, K800, K800i, other
Sunrise: T868, other
Suntec: E592, other
Suny-ericssom: Cyber-shot-P999, K770, K900, other
SuperFone: SF-9080, other
SVA: F08, other
Svmsunc: i908, other
Swaahoo: S709, S93, S95, S96, S97, other
Swatch: M300, Nova-N800, other
Swatch-Mobile: M300, other
TAG: Heuer-RM267v, other
Taixing: D008, other
Taxco: DM79, DM87, TX60, other
TCL: 3188+, 3188M, 3188U, 718, 728, 738, A288, D569, D659, E330, GQ05, M361, M388, M530, M580, M586, M819, Q510, Q515, Q550, T106, T108, T550, T558, T766, T939, U58, U80, V18, V6, other
Techno: X780i, other
Tecno: D100, M280, ST600, ST880, T600, T800, T880, V410, V500, V801, V90i, X200, X200i, X210, other
Telit: T200, T250
Telsda: 319, 319+, 349, A318D, B1000, E65, KQ108, T090, T915, TS617, TS627, TS637, other
Tesco: T3, other
Tethin: S350, other
Tevion: MD96110
Thin: K600+, other
Thomson: TH102, TN320, TN710
Thrus: D98, other
TIA: TD20
Tian-Wai: 508, other
Tianyu: A699, B830, M99, S655, other
Tiger: 7710, 7712+, 7718, KF928, other
Tintele: TT-N1-Black, TT-N1-Gold, TT-V2, TT-V33, other
Titan: V70, V71, other
T-Mobile: Vairy-Touch, X760
TOCS: C64, C68, M52
TOMSIM: C90E, other
Top: S21, S23+, other
Torque: D90, other
Tosello: Spatola, other
Toshiba: TS10, TS30, TS608
Toshibo: Q300, V8, V9+, other
Touch: 568, other
TouchPhone: i9, other
Trend: T100, T101, T181, T200, T300, T303, T500, T505, T555, T786, other
Trident: MB-1100, other
Trus: D98, D99, other
TSD: T619, TD630, TS806, other
TTK: N82, other
TvMobile: C702, Q1, T737, other

TV-Mobile: V702, other
TwinSim: T60
TWZ: TD8, other
UCOO: U38, other
Ufo: 833, 995, Digital-Mobile, other
Ultra-Slim: M9, other
UP-Tec: TV-Mobile, other
Usha-Lexus: 777B, 789B, 800B, 828B, 838B, other
UTEC: S898, other
UTstarcom: 1238, C620, G520, GPRS1328, GPRS568, GPRS748, GPRS749, GPRS758, GPRS778, GPRS779, GSM708, GSM718, GSM719, other
Vaic: A1900, A618, Strike-TV-Mobile, T800, other
Vaio: 5MP, 7MP, A328, A447, A968, other
Vairy: Touch
Vave: S70, other
VCall: V329, V850, V929, other
Venus: S90, V300, V308, V900, other
Veon: T10, other
Veptu: 8088, N888, N888c, N888i, other
Verykool: i250, i300, i405, i410, i500, i700
V-Fone: 328, other
Vigoo: C3000, K791, K902, K918, other
Vimaxx: V88, other
Virgin: Fly-SX200, Lobster-485, Lobster-544, Lobster-575, MicroSnapper, V-Slide, V-Touch
VirtuV: V989, other
Vision: H8, other
Vitel: TSM1, TSM2, TSM3, TSM4, TSM5m, TSM6
VK-Mobile: VG207, VK1500, VK180, VK200, VK200_unlock, VK2000, VK2010, VK2020, VK2030, VK207i, VK3100, VK4000, VK4500, VK500, VK518, VK520, VK530, VK540, VK550, VK560, VK570, VK580, VK700, VK800, VK900
Vodafone: 123, 125, 225, 225FM, 226, 226FM, 227, 228, 235, 331, Indie
Voice-Mobile: V31, V45, V51, other
Voxtel: 1iD, 2iD, 3iD, BD50, BD60, RX11, RX600, RX800, V350, V50, V500, VS600, VS800
VS&ME: V300, other
Wailung: N82+, other
WatchPhone: A007, Apoda, M500, M800, M801, M810, V2, W08, W688+, Z5000, Z5100, Z5200, other
Wellcom: BM1, DM1, DM2, DM3, DM5, DM8, L358, L388, SM1, W110, W111, W310, W310LCD, W330, W350, W501, W503, W520, W538, W801, W803, W810, W811, W818, W818FM, W818LCD, W819, W820, W829, W838, W910, W920, W930, W980, other
Wemo: T900, other
Wentto: DG699, other
Widetel: WT-T600, other
XDF: N58, other
XDS: V890, W890, other
XED: X689, other
XEN: XN501, other
XiMax: A638, other
XinBao: 2632, 2638, other
Xingtai: 338, other
Xintai: T800+, other
XinTaio: T800+, other
XKSSTEL: S4, other
X-Max: X1000, other
XTelecom: X3128, X3128+, X3128B, X9118, X9128, X9138, X918, X9199, other
XTTel: C3000+, C5000+, C7000+, other
Xunchi: 138, other
YaXing: E50, V800, V808, other
Yes-Optus: D736
Yingtai: TV2000, TV7000, other
Zetel: N82y, N95y, N95Y+, N96y, other
Zetta: A10
ZMC: A100, other
ZMEM: 1075
Zoho: 5800, G700, S859+, V88+, other
Zonda: 1075, 1075R, 1085, 1090, 1095, 1095R, 1099, G1840, G1860, G1880, Levis, MZ9, N2000
Zong: A136
ZT: 2688, 303, 3188, 321, 326, 5188, 579, 588, 6618, 6668, 710, 8118, 9198, 999, C92+, K699, N6168, other
ZTC: 111, 168, 169, 2009, 268, 369, 532, 555, 588, 618, 6588, 660, 6618, 6628, 663, 666, 6688, 699, 777, 777i, 778, 787, 818, 8188, 866, 868, A108, A168, A231, A281, A287, A5, A688, A818, A838, A868, A898, A990, C10000, C118, C300, C600, D1100, D1110, D1112, D1117, D1120, D1200, D828, DC818, DC888, DY579, DY579+, E550, E86, F1, F16B, F480, F688, F882, F897, H18, H5, H668, H688, H998, IP9300, JC599, K118+, K119, K127, K600, K650, K650i, K700, K900+, K910, LV918, M608, M618, M98, M99, N100, N101, N107, N328, N328-blueteech, N329, N38, N39, N689, N880, N880+, N95, P8500, Q530, Q531, S508, S508+, S600+, S888, SL88, T118, T518, T58, T63, T63i, T64, T699, T85, T85e, T88, T88i, TV88,

V66, X668, X668+, ZT003, ZT009, ZT018, ZT019, ZT11, ZT123, ZT1588, ZT1598, ZT160, ZT168, ZT1689, ZT169, ZT188, ZT199, ZT2008, ZT2087, ZT2088, ZT2180, ZT268, ZT2688, ZT303, ZT3188, ZT321, ZT321-6226, ZT321-6228, ZT321-TVmobile, ZT325, ZT326, ZT33, ZT3328, ZT508, ZT511, ZT5168, ZT5188, ZT528, ZT5680, ZT5688, ZT58, ZT580, ZT582, ZT588, ZT588+, ZT608, ZT6099, ZT6588, ZT6618, ZT6618-PDA, ZT6628, ZT666, ZT6668, ZT668, ZT6688, ZT6698, ZT6699, ZT678, ZT68, ZT698, ZT699, ZT710, ZT8008, ZT8088, ZT8089, ZT8099, ZT8118, ZT8188, ZT82, ZT8380, ZT86, ZT868, ZT8828, ZT8828+, ZT888, ZT8886, ZT8898, ZT8899, ZT89, ZT890, ZT8900, ZT898, ZT918, ZT9198, ZT928, ZT9288, ZT968, ZT988, ZT989, ZT999, ZT999e, ZTM608, ZTN329, ZT-N6128, ZTS508, other
ZTE: 123, 125, 195, 201, 2010, 202, 203, 204, 225, 225FM, 226, 227, 228, 231, 7310, 7610, A12, A12+, A136, A136G, A139, A15, A16, A201, A201+, A205, A205+, A206, A208, A211, A212, A213, A215, A215+, A261, A292, A301, A35, A35FM, A36, A36+, A36FM, A37, A39, A61, A611, A62, A62+, A66, A68, A80, A831, A832, A833, A861, A931, A933+, C335, C632, Coral-200, F120, G-R231, G-S212, G-X760, H500, i766, R231, S212, WP626, X760, X761, X960, other

Supported CDMA models
Huawei: C2205, C2285, C506
Nokia: 1255
Motorola: C141c, W150, W150i, W170, W170C, W200, W210, W355
ZTE: Classic 201, 202, 203, 204, C335
Samsung: SCH-B239, SCH-B259, SCH-B279, SCH-B309, SCH-B399, SCH-E159, SCH-F302, SCH-F679, SCH-S189, SCH-S229, SCH-S259, SCH-S269, SCH-S279, SCH-S299, SCH-S339
Rainbow-mts: S189

General product decription
Key features:

- **Multilanguage User Interface (MUI):**
  Arabic
  Czech
  Espanol
  Farsi
  French
  German
  Indonesian
  Italian
  Portuguese-BR
  Romanian
  Russian
  Slovenscina-Slovenian
  Srpski
  Thai
  Turkish
  Vietnamese
  More languages is under translation
- GSM and CDMA models supported
- standalone software (no Internet connection required)
- sp-unlock: unlock (remove/clear) network, provider locks
- set network, provider locks
- read unlock codes
- flash read/write (high speed)
- write any part of flash separately (firmware, customization, flex, map, file system (ffs), language pack)
- upgrade/downgrade firmware
- repair damaged imei
- remove/clear/read user/phone/lock code
- reset to default/factory settings
- repair dead phones
- read flash/eeprom area backup
- repair software-related problems
- read unlock codes: network, provider codes, user/phone code
- empty board flashing (f.e
- after flash chip replacement)
- format file system
- make security zone backup during critical operations
- **"smart write"** option, together with high-speed option flashing speed may be extremely high
- detect keyboard codes by flash file ("Keyboard codes detector")
- save operation process results in Log file
- big flash files database for **all World regions**
- compact flash/eeprom files format: flash/backup files internally packed and unpacked on-fly so you can save up to 50% of your Internet traffic (download small files from support area) and a lot of disk space on HDD for file storage
- counter for unlock/flash/other operations
- easy to use brand/model selection via **"Shell"**

- easy access to cables/pinouts information via **"Cable selector"**
- easy access to support area via automatic login system and **"Support manager"**
- huge flash files database (firmware, language pack, flex, map, repair eeprom, ffs files etc.)
- documentation and manuals with step-by-step instructions

Note: to avoid any misunderstanding, please, check list of available functions for each supported model, different models has more/less functions in order to hardware/software limitations !

"Chinese Miracle" module for MT6205-MT6230 CPU based models:

- automatic phone structure detection: this means that you can also service phones that not shown in supported models list, just find a pinout and be sure that your phone based on MT62xx CPU and you will be able to flash/unlock/repair this phone.
- repair dual-sim (dual-CPU) models: work with Rx_A/Tx_A, Rx_B/Tx_B pinouts to repair firmware for both CPU
- repair imei for mono-sim and dual-dual models with different methods (MT6205, MT6223 dual configurations suppported too)
- repair imei for single SIM/CPU models
- repair master imei (sim-1) for dual SIM (dual CPU) models
- repair slave imei (sim-2) for dual SIM (dual CPU) models
- repair master imei (sim-1) for dual SIM (single CPU) models
- repair slave imei (sim-2) for dual SIM (single CPU) models
- repair slave imei (sim-3) for triple SIM models
- automatic memory size detection
- direct sp-unlock phones with unknown firmware (autodetection algorithm)
- direct unlock user code phones with unknown firmware (autodetection algorithm)
- format filesystem: autodetect ffs structure and size, backup ffs before format
- reset to defaults phones with unknown firmware (autodetection algorithm)
- write/Read flash for phones with unknown structure (autodetection algorithm)
- write/Read eeprom for phones with unknown structure (autodetection algorithm)
- firmware version autodetect
- automatic firmware version detection and save original firmware version information in Log file during flash/format (very important for repair phones w/o backup)
- language list autodetect
- repair "Power-On problem" for MT6223, MT6225, MT6226, MT6227, MT6228 based models after full flash w/o backup, erased flash etc.
- repair/recalculate security area to repair dead phones based on MT6223, MT6225, MT6226, MT6227, MT6228
- upgrade/downgrade phone firmware
- unlock (remove/clear) network, provider locks
- read unlock codes: network, provider codes, user/phone code
- reset phone settings to defaults (factory state)
- empty board flashing (f.e
- after flash chip replacement)
- make security zone backup during critical operations
- repair software-related problems
- repair dead phones
- "Flash File Manager": easy access to firmware information such as internal firmware name, language names, keyboard codes
- touchscreen calibration (repair phones with damaged touchscreen)
- repair "bad software" fault (latest MT6223, MT6225, MT6226 based models)
- detect language names inside flash file
- detect keyboard codes inside flash file (for service menu etc.)
- detect firmware version by flash file
- detect existing languages by flash file
- detect keyboard codes by flash file ("Keyboard codes detector")
- batch flash file rename, version detection, language detection, name conversion
- save operation process results in Log file
- huge flash files database (firmware, repair eeprom, ffs files etc.)
- documentation and manuals with step-by-step instructions

Sony-Ericsson T250, T280, Z250, Z320

- direct sp-unlock

flash read/write (high speed)

Sony-Ericsson K200i, K205, K220i

flash read/write (high speed)

"smart write" option, together with high-speed option, flashing speed can be extremely high

reset defaults/format ffs (repair software bugs)

user code

sp-unlock (direct, unlimited, fast)

repair dead phones (after cloned eeprom)

repair "camera not save"

Sagem: my150x, my220v, my220x
.direct sp-unlock

Sony-Ericsson J110i, J120i

flash read/write (high speed)

flashing any part (main/language pack/flex) together or separately

"smart write" option, together with high-speed option, flashing speed can be extremely high

phone type check to avoid wrong flashing

reset defaults/format ffs (repair software bugs)

user code

sp-unlock

repair "unauthorized phone"

repair dead phones

direct sp-unlock

flashing any part (main/language pack/fex) together or separately

high speed support

clear phone code

flash reading

"smart write" option, together with high-speed option, flashing speed can be extremely high

repair erased boot-core without desolder flash chip

imei repair

repair "phone hacked"

Motorola c168, c168i, w220

flash read/write (high speed)

flashing any part (main/language pack/flex) together or separately

"smart write" option, together with high-speed option, flashing speed can be extremely high

phone type check to avoid wrong flashing

reset defaults/format ffs (repair software bugs)

user code

sp-unlock (all firmware versions)

repair "unauthorized phone"

imei repair (any digit)

Panasonic X100, A200, X500, G60

flashing software auto-detect phone version and offer to skip flash part that is the same

"Safe Mode" option to prevent phone death with empty battery

flash different region phones (f.e.: Asian to Euro, Euro to Asian)

decustomization (operator logos, wap settings etc.)

fast and real Imei repair, old Imei not come back after future flashing

flash reading

repair G60, X500 erased boot-core w/o flash chip desoldering

Panasonic GD55, G50, G51E, G51M, G51U, G70, A100, A101, A102, X300, A210, SC3

flashing software auto-detect LangPack structure and check existing/new LangPack compatibility (not supported for GD55 due to GD55 has no separate LangPack flash part)

reset phone user settings to default factory values (RF,BAT etc
calibration values not resetted)

flash different region phones (f.e.: Asian to Euro, Euro to Asian)

decustomization (operator logos, wap settings etc.)

dast and real Imei repair, old Imei not come back after future flashing (A210, SC3 not supported yet)

flash reading

sp-unlock

lock to specified Network (SC3 not supported yet)

A100,A101,A102,X300 "No network" problem repair after bad unlock/flashing with other software

"Backup" option for critical operations

non-stop flashing mode

repair after empty-battery flashing

fast speed flashing

repair eeprom

Panasonic X60, X66, X68, X77, X200, X400, A500:

flash phones that can not Power-On after bad/terminated flashing

reset phone user settings to default factory values (RF,BAT etc
calibration values not resetted)

flash different region phones (f.e.: Asian to Euro, Euro to Asian)

decustomization (operator logos, wap settings etc.)

repair "Restarting" problem, as well as other software problems

flash reading

hidden Language activation

repair after empty-battery flashing

Panasonic VS2, VS3, SA6, MX6, VS6, VS7, SA7, MX7:

sp-unlock

flashing

fecustomization

flash phones that can not Power-On after bad/terminated flashing

flash different region phones (f.e.: Asian to Euro, Euro to Asian)

flash reading

high speed supported

reset defaults during flashing

hidden Language activation

Panasonic X700, X701

sp-unlock
Imei repair

clear user code

Panasonic X70

unlock all software versions

clear phone memory

set user settings to factory defaults

clear Lock code/User code

Bird S198, S199, S1186

fast sp-unlock (several seconds only)

clear user code/phone lock/super password

repair Imei

LG KG110, KG120, KG220, KG225, KG240, KG280, KG320, L342i, L343i, B2050, B2060, B2100, C2200, MG101, MG120, MG225, MG230, MG280, MG320, KP200, KP202, C1100

direct sp-unlock

eeprom read/write (high speed)

flash read/write (high speed)

reset default settings

LG KE600, KE770, KE800, KE820, KE850, KE970, KG270, KG271, KG275, KG276, KG278, KG275, KG288, KG289, KG370, KG375, KP106, MG160
MG161, MG165, MG180, MG370

read unlock codes

direct sp-unlock

eeprom read/write (high speed)

flash read/write (high speed)

reset default settings

reset user/security code

imei repair

LG-KF600

direct sp-unlock

LG G1800, C2500, C2600, KG190, KG200, KG300

direct sp-unlock

user code reset

flash read/write (high speed)

repair imei

Motorola C113, C113a, C114, C115, C115i, C116, C117, C118, C121, C136, C138, C139, C140, C155, C156, C157, V170, V171, V172, V173, C257, C261, V175, V176, V177, W370, W375

read sp-unlock codes

direct sp-unlock

repair Imei for w370/w375

flashing any part (Main/Language Pack/Flex) together or separately

high flashing speed supported

upgrade/downgrade firmware

"Safe Mode" option to prevent death with empty battery (not supported for C113-C118)

phone type check to avoid wrong flashing

current/new firmware version check during flashing to save time

clear phone/user code

flash reading

"Smart write" option
Together with high-speed option flashing speed can be extremely high

Repair dead C113, C113a, C114, C115, C116, C117, C118, C121, C115i, C136, C138, C139, C140, C155, C156, V170, V171, V172, V173 erased boot-core without desolder flash chip

unlock newest C113-C118, C121, C122, C123,C136, C138, C139, C140 via test-point
C113, C113a, C114, C115, C115i, C116, C117, C118, C136, C138, C139, C140 Imei repair

unlock newest C113-C118 w/o flashing

Motorola F3

sp-unlock

flash firmware/language pack/flex

high speed supported

format ffs

reset defaults

clear call history

Motorola w205, w208, w209, w215, w218

sp-unlock

clear phone/user code

read phone information

flash write (firmware/LP/Flex together or separately)

high speed supported

Motorola V690, V872, V878

flash write/read (high speed)

flashing any part (main/language pack/flex) together or separately

"Smart write" option
Together with high-speed option flashing speed can be extremely high

upgrade/downgrade firmwar

phone type check to avoid wrong flashing

user/lock code reading

Fly/VK VK2000

flash write/read (high speed)

user/lock code

imei repair

reset defaults

empty board flashing

VK-Mobile VK200

sp-unlock

imei repair

user/lock code reset

reset defaults

VK-Mobile VK2010, VK2020, VK3100, VK4000, VK4500

imei repair

user/lock code reset

reset defaults

Fly/Bird S288, S688, S788, S299, D736, Amstrad S288

flash write/read (high speed)

sp-unlock

reset user code

reset phone settings to default factory values (RF,BAT etc
calibration values not resetted)

repair software bugs (freez/restart etc.)

repair after empty-battery flashing

Fly/Bird S1180C, Bird V09, Bird V10

flash write/read

reset phone settings to default factory values (RF,BAT etc
calibration values not resetted)

repair software problems (freez/restart etc.)

user/lock code reset

Siemens ST55, ST60

sp-unlock

lock to specified Network

fast and real Imei repair

reset user settings to default (during flashing)

flash write/read (high speed)

repair after empty-battery flashing

Siemens CL75

fast sp-unlock

reset user settings to default

flash write/read (high speed)

repair after empty-battery flashing

repair eeprom

Siemens CFX65

fast sp-unlock
reset phone settings to default factory values (RF,BAT etc
calibration values not resetted)

flash write/read (high speed)

decustomization

phone/user code reset

repair after empty-battery flashing

"Smart write" option
Together with high-speed option flashing speed can be extremely high

Nec E101, N342i, N343i, N344i, N650i

fast sp-unlock
lock to Network (N343i, N344i not supported)

fast and real Imei repair (N343i, N344i not supported)

reset user settings to default

flash write/read (high speed)

non-stop flashing mode

repair after empty-battery flashing
repair eeprom

Nec E122

flash write/read (high speed)

reset user settings to default (repair freez/startup problems)

Philips-568

fast direct sp-unlock

unlock code calculation by Imei

lock to Network

reset user settings to default (during flashing)

flash write/read (high speed)

non-stop flashing mode

repair after empty-battery flashing

Philips-S200, S220, S660, S800, S880, S890, 290, 390

direct sp-unlock

read unlock codes

read/clear user code

reset user settings to default

flash write/read (high speed)

repair after empty-battery flashing

VK-Mobile VG207, VK207i, VK300, VK310, VK320, VK330, VK500, VK518, VK520, VK530, VK540, VK550, VK560, VK570, VK580, VK800, VK900

fast sp-unlock

imei repair

reset to defaults

flashing (VG207, VK300, VK310, VK320, VK330 not supported)

fast flashing speed support

upgrade/downgrade firmware

"Smart write" option
Together with high-speed option flashing speed can be extremely high

flash reading (VG207 not supported)

American models supported too

VK-Mobile: VK700

repair freez/restart bugs

BenQ-Siemens: O2X4, S80, S82, SFG75

read unlock codes

Sanyo: S750

direct sp-unlock (some versions is not supported yet)

Alcatel: E101, E201, E207, E221, E227, V270

direct unlock

flash write/read (high speed)

user code clear

imei repair

Alcatel E15x/16x/25x

read unlock codes

Alcatel: OT152, Audiovox GSM609, BenQ O2X3, BenQ S700, BenQ A500

fast sp-unlock

user/lock code reading

flash write/read (high speed)

Alcatel: OT-C700A, OT-C701A, OT-C701X, OT-C707, OT-C717, OT-C820A, OT-C825, OT-C825A, OT-S520, OT-V770X, ELLE-N3, LAVA, Mandarina-Duck

sp-unlock

user/lock code reading

flash write/read (high speed)

reset user settings to default values

flash empty-board (completely erased) chip

repair imei

O2X1i, O2XLI, O2X1b, O2X2i, BenQ-Siemens M300, M305, M315, M350, E61, C71A, CF61, EF61, CL71, M100, A38, Bird S570, Siemens AP75

fast sp-unlock

flash separately Firmware/LangPack/Flex (high speed)

eeprom backup/repair

flash reading

user/lock code clear

BenQ-Siemens: S88

user/lock code clear

Hyundai: H350

flash write/read (high speed)

repair freez/restart problems

reset user settings to default values

reset user/lock to default value

repair imei

Toshiba: TS10

sp-unlock

flash write/read (high speed)

reset user/lock settings to default values

Fly: Z200, Z300, Z300a, Z400, Z500, X3, X7

sp-unlock

flash write/read (high speed)

reset user settings to defaults

repair software faults/freez etc.

reset user/lock code to defaults

repair imei

Newgen: Mars, C610, C620, C710, C800, C1000, E1000, E1100, E1200, T1000, S410, Airness: AIR99, Geo-G1, Geo-Gv880

sp-unlock

flash write/read (high speed)

reset user settings to defaults

repair software faults/freez etc.

reset user/lock code to defaults

repair imei

Nec: N200, N208, N910, N916, N917, N919

sp-unlock

flash write/read (high speed)

reset user settings to defaults

repair software faults/freez etc.

reset user/lock code to defaults

repair imei

KN-Mobile: KN200, KN300, KN310, KN400, KN500

sp-unlock

flash write/read (high speed)

reset user/lock settings to defaults

repair software faults/freez etc.

reset user code to defaults

repair imei

Hyundai: MP510, MP718, MP728, MP738

flash write/read (high speed)

repair software faults/freez etc.

TCL: 3188, 3188+, 3188U, Q510, Q515, 718, 728, 738, T550, T939, GQ05, Nerys-N330

sp-unlock

flash write/read (high speed)

Konka: C625

sp-unlock

repair imei

user/lock code clear

flash write/read (high speed)

TOCS: C64

sp-unlock

repair imei

user / lock code clear

flash write / read (high speed)

Thomson: TN320

sp-unlock

user / lock code clear

flash write / read (high speed)

Konka: C926, C966, EC001, A26M, M910, D163

sp-unlock

user / lock code clear

flash write / read (high speed)

Asus: V75, V80

sp-unlock

user / lock code clear

flash write / read (high speed)

I-Mobile: 301, 306, 308, 508, 510, 511, 600, 601, 602, 603, 604, 606, 608, 610, 901, 902

sp-unlock

user / lock code clear

flash write / read (high speed)

DBTel J6, Emblaze Sting6, Medion MD95100 / 2860, Thomson TN710

sp-unlock

repair blocked counter

rset defaults

flash write / read (high speed)

Vitel: O2X7

sp-unlock

flash write / read (high speed)

Virgin Lobster485, Lobster544, Lobster575, Audiovox GPRS748, My Way MW100, Voxtel-RX11, Voxtel-V500, UTStarcom GSM708, GSM718, GSM719, GPRS758, GPRS779

sp-unlock

user / lock code reset

flash write / read (high speed)

Virgin Micro Snapper

sp-unlock

flash write / read (high speed)

Zonda: G1840, G1860, G1880

sp-unlock

flashing (full or any part of flash separately) (high speed)

reset user settings to defaults

repair software faults/freez etc.

reset user/lock code to defaults

flash reading

repair imei (function under test)

Fly: V40, M100, SL200, MP220

sp-unlock

user/lock code reading

flash write/read (high speed)

Lenovo: E300, E307, P708, P710

sp-unlock

user/lock code reading

flash write/read (high speed)

Dirland: E307

sp-unlock

user/lock code reading

flash write/read (high speed)

AK-Mobile: AK760i

sp-unlock

user/lock code reading

flash write/read (high speed)

Fly: 2040, 2040i, 2080, MX200, MX200i, MX230, MX300, MX330, SL300m, SL400m, SL500m, SL500i, SL600, Sl600-Vodafone, SX240, SX300, MP300, MP400, MP500, MP600, Lenovo V707

sp-unlock

user/lock code clear

reset defaults

repair imei

flash write/read (high speed)

Spice: S400, S404, S410, S415, S450, S500, S530, S540, S555, S600, S600N, S640, S5, S8, S800, S900, D88

sp-unlock

user/lock code clear

flash write/read (high speed)

imei repair

Skyzen: EZ300, EZ400, EZ500, EZ600, EZ800

sp-unlock

user/lock code clear

flash write / read (high speed)

imei repair

Pantech: C120, C3, C3B, G3900, G800, G900, GB300, PG-1000, PG-1200, PG-1210, PG-1400, PG-1405, PG-1410, PG-1500, PG-3000, PG-3200, PG-3210, PG-3500, PG-3600, PG-3810, PG-6100, PG-C300

sp-unlock

lock to network

flash read (high speed)

flash write (high speed) (not supported for several models)

Pantech: PG-1000

sp-unlock

flash / eeprom write / read (high speed)

Aiko: 17G, 51G, 52G

sp-unlock

user / lock code reset

flash write / read (high speed)

high speed supported

Gradiente: GF500, GF760, GF910(i), GF930(i),GF950, GF970, Vibe

sp-unlock

user / lock code reset

flash write / read (high speed)

Voxtel: VS600, VS800, RX600, RX800
sp-unlock

user / lock code reset

flash write / read (high speed)

Airtel Cordless FGD8900

sp-unlock
flash write / read (high speed)

user / lock code clear

Sitronics: SM8190, SM8290, Enteos i-BD620

flash write / read (high speed)

reset factory defaults

Ezio / Elson: MP500, E800, SL308, SL388, ESL808, SL900

sp-unlock

user / lock code reset

flash write / read (high speed)

O2-Jet(J1)

sp-unlock

user / lock code clear

write / read flash

high speed (up to 921600) supported

Orange: TR1

sp-unlock

user / lock code clear

write / read flash

high speed (up to 921600) supported

Tecno: D100, V410, V500, X200, X200i, X210, M280, T800, V801, V600

user / lock code clear

imei repair

write / read flash

high speed (up to 921600) supported

Samsung: C140, C140i, C260, C260M, C266, X120, X140, E900, C300

sp-unlock

Bleu: 551x, 651x, 651Z

user / lock code clear

imei repair

write / read flash

high speed (up to 921600) supported

ZTE: Classic 2010, A12, A12+, A15, A16, A37, A39, A80, WP626

sp-unlock

write / read flash

reset settings

imei repair

high speed (up to 921600) supported

Coral: 300

sp-unlock

write / read flash

reset settings

imei repair

high speed (up to 921600) supported

Motorola CDMA: W150, W150i, W170, W170C, W200, W210, W355, C141c

user / lock code read

flash read

flash write

esn repair

Huawei: C2205, C2285, C506

user / lock code read

ZTE: C335, C632

user / lock code read

Nokia: 1255

user / lock code read

ZTE: Classic 201, 202, 203, 204 CDMA

read user code

detect SPC code

ZTE: 125, 225, A35, A36, A61, A62

flash read / write

direct sp-unlock

user / lock code reset

reset to default values

Coral: 200

flash read / write

direct sp-unlock

user / lock code reset

reset to default values

Haier: Z1000

flash read / write

sp-unlock

ZTE: 7310, 7610

flash read / write

sp-unlock

Bleu: 251s, 251x

fast sp-unlock (several seconds only)

clear user code / phone lock / super password

repair Imei

Hyundai: L480

fast sp-unlock (several seconds only)

clear user code / phone lock / super password

repair Imei

Zestaw zawiera:

Infinity box
Zestaw kabli

É 2022 www.gsm-support.net

Opis ten nie stanowi oferty w rozumieniu Kodeksu Cywilnego. GSM-Support zastrzega sobie prawo do moÕliwych bţňd·w w opisie produktu.
Prosimy o weryfikacjň z PaŒstwa strony, a w razie wŃtpliwoŜci o kontakt.

GSM-Support
ul. Dobrego Pasterza 102/5
31-416 Krak·w
POLSKA
tel. 608107455
e-mail: sales@gsm-support.pl